

- **SchemaView Plus**

- User Comments in Displays and Database Points – this feature allows the addition of comments on displays. Any comment written on a display will appear on all other workstations showing or bringing up that display
- FTP Display Publication – allows a display to be “published” to a library location – Based on a user configurable setting, the display will automatically be updated, or the user will be prompted for an update of the new display
- Hot Links to Other Applications – An area on the SchemaView display can be defined as a link to another application. Clicking on the area will result in starting of the user definable application

- **SchemeView NAV**

- Assign Function Keys F1-F12 to SchemaView displays. Depressing the Function Key brings up the assigned display.
- Scroll forward and back through display history by depressing Forward / Back arrows.

