

SchemaView Plus Features:

- **User Comments**—the user can add comments to displays. Any comment added to a display will appear on all other workstations showing or bringing up that display.
- **Device Comments** – any point can have one or more comments added and viewed. When a device has one or more comments, a “C” will be added to the device attribute (TIOC) fields on SchemaView, ListView and EosExplorer Displays.
- **FTP Display Publication** – a display can be “published” to a library location – A display on view at another workstation will either automatically be updated, or the workstation user will be prompted to update of the new display.
- **Application Selection** – areas on displays can link to other applications. Clicking on an area will start the application with an executed file.

SchemaView NAV Adds:

- Display Call-up Keys -- assign Function Keys F1-F12 to SchemaView displays. Depressing the Function Key brings up the assigned display.
- Forward/Back buttons -- scroll forward or back through display history by pressing these buttons.

